







LE1362_SOH73XXX

		Spare part number	Spare part number	Colours available
1	Glass lid (Smoke black)	SSPA0234		.BK
	Glass lid (Solid black)	SSPA0233		.SBK
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy (=incl. nr 10)	SSPA0600		
4	Pan support	SSPA0969		
5	Pan support clips 4x	SSPA0041		
	Pan support clips 50x	SSPA0042		
6	Bump stops 2x	SSPA0040		
7	Hotplate 800W	SSPA0550		
	Hotplate 1000W	SSPA0551		
8	Burner assy (medium)	SSPA0117		
9	Burner assy (small)	SSPA0103		
10	Thermocouples hob		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0676	SSPA0670	
	Production date: ≥ 01-07-2015 (≥ E182S...)		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0676	SSPA0670	
11	Spark electrode 4x	SSPA0310		
12	Gas tap oven	SSPA0452		
13	Gas tap grill	SSPA0472		
14	Spark ignition button (=incl. switch)	SSPA0381		
15	Light switch <i>*not all models</i>	SSPA0591		
16	Gas tap burner 1x	SSPA0432		
17	Hotplate switch	SSPA0580		
18	Lamp, indicator hot plate	SSPA0561		
19	Control knobs	Refer to page 3		
20	Grill door	Refer to page 3		
21	Oven door	Refer to page 4		
22	Lower door <i>*only for 3/4 height</i>	Refer to page 4		
23	Glass, inner door	SSPA0253		
24	Oven door seal	SSPA0062		
25	Oven shelf x1	SSPA0980		
26	Grill pan	SSPA0991		
27	Oven lamp <i>*not all models</i>	SSPA0560		
28	Oven burner	SSPA0191		
29	Thermocouple oven	SSPA0642		
30	Electrode oven	SSPA0321		
31	Grill burner			
	Production date: < 13-04-2015 (>E103S....)	Not available		
	Production date: ≥ 14-04-2015 (<E104S....)	SSPA0185		

		Spare part number	Spare part number	Colours available
32	Thermocouple grill			
	Production date: < 01-07-2015 (<E182S....)	SSPA0643		
	Production date: ≥ 02-07-2015 (>E183S....)	SSPA0644		
33	Electrode grill	SSPA0321		
34	Spark generator	SSPA0399		

Control Knobs


Control Knob sets




Spare part number	SSPA0933	SSPA0901	SSPA0902
Colours available	Chrome (.CR) Capped Knobs	Gloss Nickel (.GNK) Matt Nickel (.MNK) Satin Chrome (.SCR)	Chrome (.CR) Satin (.SA)
Set quantity	6	6	6

Cladding styles


No cladding



Side cladding



Behind handle cladding




Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3425.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3425.BK4X	Clear	Black	Bottom Horizontal	N/A		Stainless
SMAO3425.BK1X	Clear	Black	No	N/A		Stainless

Oven door styles


Drop down oven doors



Left hinged oven doors



Right hinged oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3445.BK/SVS10X	Clear	Faded dots	No	N/A		Satin
SMAO3445.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3445.BK1X	Clear	Black	No	N/A		Stainless
SMAO3445.BK2X	Clear	Black	Yes	Bottom Horizontal		Stainless
SMAO3445.BK16X	Clear	Black	No	N/A		Chrome
SMAO3445.BK3X	Clear	Black	No	N/A		Bright nickel
SMAO3445.BK9X	Clear	Black	No	N/A		Chrome satin

Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3460.SS	Clear	Black	No	N/A	N/A	N/A
SMAO3460.MIR	Clear	Mirror	No	N/A	N/A	N/A
SMAO3460.BK	Clear	Black	No	N/A	N/A	N/A